

	SO 106 - Souřadnice S-JTSK	
č.b.	Y	X
600	472897,9529	1107051,9941
601	472897,9616	1107052,1160
602	472897,9295	1107051,8741
603	472896,5967	1107046,7507
604	472900,6495	1107050,4142
605	472901,0947	1107051,0150
606	472901,8322	1107051,1391
607	472901,9789	1107051,1066
608	472897,9970	1107055,7067
609	472902,0182	1107055,6670
610	472902,3374	1107053,8228
611	472903,8474	1107052,7170
612	472922,6328	1107040,9823
613	472924,8808	1107038,9169
614	472929,5441	1107032,6018
615	472932,5361	1107025,3441
616	472934,1918	1107018,5564
617	472934,2338	1107017,8380
618	472934,0187	1107017,1512
619	472932,2065	1107013,7066
620	472931,1822	1107013,4583
621	472926,3945	1107007,7745
622	472931,5669	1107009,0265
623	472933,1176	1107009,7550
624	472934,2217	1107011,0653
625	472937,7340	1107017,7411
626	472938,2258	1107018,2883
627	472938,9186	1107018,5358
628	472939,2191	1107018,5970
629	472938,2656	1107023,3182
630	472937,8703	1107023,2643
631	472935,7760	1107023,7574
632	472934,5504	1107025,5259
633	472934,4724	1107025,8460
634	472931,2853	1107033,5857
635	472914,3035	1107048,8084
636	472926,3096	1107040,3163
637	472924,6948	1107041,8576
638	472923,6628	1107042,7248
639	472922,2123	1107006,7769
640	472910,6951	1107003,9822
641	472906,5341	1107002,9724
642	472890,9822	1106999,1981
643	472897,9929	1107004,0689
644	472892,5994	1107026,2915
645	472885,0311	1107027,5624
646	472889,7678	1107028,7543
647	472891,6086	1107029,7938

	SO 106 - Souřadnice S-JTSK	
č.b.	Y	X
648	472892,6625	1107031,6263
649	472894,8796	1107040,1563