

	SO 102 - Souřadnice S-JTSK	
č.b.	Y	X
200	472944,1100	1106888,0000
201	472943,4706	1106887,6784
202	472940,6988	1106886,8185
203	472937,8032	1106886,6236
204	472936,2334	1106886,7085
205	472934,2013	1106887,6581
206	472933,3957	1106889,7515
207	472933,7000	1106909,9400
208	472936,1447	1106930,9958
209	472936,4078	1106931,5636
210	472936,9569	1106931,8639
211	472943,1838	1106932,9602
212	472941,6500	1106952,8700
213	472940,2500	1106970,1800
214	472939,7600	1106975,9500
215	472939,4800	1106978,5100
216	472936,4900	1106990,8300
217	472932,9076	1107005,7674
218	472928,0490	1107004,5902
219	472927,2933	1107004,7061
220	472926,8417	1107005,3230
221	472925,4093	1107011,1819
222	472925,5264	1107011,9391
223	472926,1450	1107012,3911
224	472931,0004	1107013,5685
225	472925,2798	1107036,6805
226	472921,3204	1107035,7139
227	472920,6179	1107035,8003
228	472920,1485	1107036,3301
229	472919,9631	1107036,8179
230	472919,9068	1107037,3072
231	472920,0909	1107037,7639
232	472922,4282	1107040,9567
233	472912,8380	1107047,1360
234	472902,0790	1107050,9303
235	472900,6236	1107046,0493
236	472900,3910	1107045,7571
237	472900,0208	1107045,7077
238	472899,5691	1107045,8230
239	472895,5914	1107046,8450
240	472909,0527	1107035,9018
241	472905,4077	1107032,5639
242	472905,6166	1107031,5654
243	472906,5929	1107031,2697
244	472909,0514	1107031,8743
245	472913,3804	1107032,9390
246	472914,1082	1107033,6538
247	472913,8301	1107034,6353

	SO 102 - Souřadnice S-JTSK	
č.b.	Y	X
248	472920,3134	1107010,9659
249	472910,4805	1107008,5476
250	472909,8661	1107008,0980
251	472909,7462	1107007,3461
252	472910,8862	1107002,5315
253	472911,3372	1107001,9090
254	472917,0686	1107003,0056
255	472912,0967	1107001,7905
256	472922,7010	1107001,1987
257	472917,8209	1107000,0158
258	472923,3197	1107001,6508
259	472923,4368	1107002,4081
260	472921,5236	1107010,2323
261	472921,0706	1107010,8500
262	472924,3504	1106972,8179
263	472924,6857	1106971,3559
264	472929,0718	1106972,3620
265	472929,3837	1106972,5838
266	472929,4474	1106972,9611
267	472929,3356	1106973,4484
268	472929,1138	1106973,7603
269	472928,7364	1106973,8240
270	472925,9656	1106966,0066
271	472927,7800	1106958,4300
272	472931,8022	1106942,0037
273	472931,9814	1106939,1650
274	472927,6100	1106938,0967
275	472928,1234	1106935,9961
276	472928,5037	1106934,9151
277	472929,0830	1106933,9263
278	472931,0533	1106933,1285
279	472932,6291	1106934,5554
280	472933,0245	1106935,9588
281	472933,2215	1106937,0087
282	472933,2292	1106938,0770
283	472932,6696	1106944,8923
284	472930,9384	1106965,9746
285	472930,5323	1106966,6997
286	472929,7182	1106966,8674
287	472923,0084	1106931,1951
288	472922,9729	1106931,3413
289	472922,7473	1106931,6502
290	472922,3694	1106931,7092
291	472920,4255	1106931,2388
292	472920,1163	1106931,0131
293	472920,0573	1106930,6348
294	472920,0932	1106930,4870
295	472921,4081	1106882,4028

	SO 102 - Souřadnice S-JTSK	
č.b.	Y	X
296	472925,8022	1106883,4718
297	472926,8926	1106884,1675
298	472927,3292	1106885,3850
299	472927,4527	1106893,5758
300	472927,6882	1106909,2004
301	472927,4505	1106909,8628
302	472926,8353	1106910,2046
303	472922,8300	1106910,8000
304	472921,3600	1106916,7700
305	472915,0100	1106942,9400
306	472908,9000	1106968,0300
307	472906,4201	1106978,4797
308	472901,4139	1106999,1688
309	472906,3075	1107000,3532
310	472906,9269	1107000,8063
311	472907,0427	1107001,5650
312	472905,8528	1107006,3781
313	472905,3999	1107006,9937
314	472904,6445	1107007,1095
315	472899,7591	1107005,9145
316	472894,7030	1107026,7470
317	472898,5901	1107027,6886
318	472899,2085	1107028,1399
319	472899,3265	1107028,8964
320	472897,4246	1107036,7325
321	472894,6908	1107040,4563
322	472890,1211	1107041,1338
323	472887,7861	1107040,5425
324	472884,1058	1107037,7994
325	472883,4414	1107033,2577
326	472885,6898	1107024,3494
327	472886,1473	1107023,7352
328	472886,9051	1107023,6248
329	472890,2000	1107024,4600
330	472895,0388	1107004,5107
331	472890,8049	1107003,4751
332	472890,1882	1107003,0235
333	472890,0706	1107002,2683
334	472891,1578	1106997,7405
335	472891,6060	1106997,1161
336	472892,3649	1106996,9941
337	472896,5964	1106998,0076
338	472901,5600	1106977,4600
339	472904,0300	1106967,1500
340	472909,9000	1106942,7800
341	472907,8003	1106942,9545
342	472907,7647	1106943,1006
343	472907,5392	1106943,4095

	SO 102 - Souřadnice S-JTSK	
č.b.	Y	X
344	472907,1613	1106943,4686
345	472905,2174	1106942,9981
346	472904,9081	1106942,7724
347	472904,8491	1106942,3941
348	472904,8850	1106942,2463
349	472916,5800	1106915,0300
350	472918,1900	1106908,3700
351	472921,7400	1106893,7800
352	472923,6821	1106885,6763
353	472919,3291	1106884,6261
354	472919,0197	1106884,4008
355	472918,9602	1106884,0228
356	472918,9951	1106883,8783
357	472919,8960	1106882,6408
358	472902,5200	1106878,1200
359	472907,6774	1106879,3335
360	472911,4157	1106882,0337
361	472912,1339	1106886,5890
362	472905,9600	1106912,0300
363	472901,3600	1106931,5400
364	472898,6300	1106942,7300
365	472893,9200	1106962,1500
366	472889,4500	1106980,6599
367	472886,7029	1106991,9794
368	472887,3663	1106996,1245
369	472887,3781	1106996,3222
370	472887,3507	1106996,5184
371	472886,1231	1107001,5768
372	472886,0569	1107001,7651
373	472885,9546	1107001,9365
374	472883,4705	1107005,2870
375	472879,2523	1107022,4967
376	472881,3819	1107023,0328
377	472881,6891	1107023,2613
378	472881,7447	1107023,6401
379	472880,3904	1107029,0057
380	472875,8503	1107035,1268
381	472868,3156	1107036,2713
382	472927,1813	1106885,5253
383	472923,3812	1106885,8606
384	472923,0141	1106911,1018
385	472917,1893	1106913,1442
386	472916,5118	1106936,1145
387	472911,6355	1106936,1064
388	472931,4239	1106958,5026
389	472905,7732	1106960,5536
390	472910,3549	1106961,4218
391	472929,6456	1106973,2867

	SO 102 - Souřadnice S-JTSK	
č.b.	Y	X
392	472901,0677	1106980,0419
393	472922,9621	1107001,0047
394	472901,3495	1106998,8588
395	472894,7369	1107004,6948
396	472899,9432	1107006,2164
397	472918,1203	1107020,9550
398	472896,6244	1107019,8531
399	472891,7208	1107018,7508
400	472913,1544	1107035,0033