

	SO 101 - Souřadnice S-JTSK	
č.b.	Y	X
1	472927,8808	1106850,9963
2	472928,1171	1106851,0553
3	472928,7416	1106851,5052
4	472928,8616	1106852,2654
5	472923,8426	1106872,9076
6	472923,3940	1106873,5237
7	472922,6415	1106873,6447
8	472921,6319	1106873,3246
9	472922,0444	1106871,5725
10	472919,1215	1106870,8842
11	472918,6694	1106872,7087
12	472927,1620	1106871,7417
13	472930,9800	1106872,6700
14	472929,0238	1106875,4345
15	472925,7900	1106876,4400
16	472925,0841	1106876,2732
17	472922,8006	1106875,7338
18	472918,4542	1106872,6526
19	472917,5353	1106867,4047
20	472919,0856	1106860,3754
21	472911,5288	1106866,4842
22	472910,9823	1106868,8460
23	472909,1850	1106871,3489
24	472906,1416	1106871,8314
25	472902,7534	1106871,0088
26	472907,0500	1106879,3400
27	472905,4348	1106885,9961
28	472904,8834	1106888,2682
29	472903,8079	1106892,6998
30	472902,9054	1106893,9359
31	472901,3932	1106894,1719
32	472899,9279	1106897,4289
33	472902,6288	1106901,8384
34	472898,6467	1106902,7127
35	472898,8718	1106917,4729
36	472894,5300	1106919,6900
37	472897,7641	1106923,0426
38	472890,2350	1106954,2210
39	472885,8625	1106972,2998
40	472882,7464	1106985,1732
41	472881,9875	1106988,2845
42	472880,6694	1106993,7383
43	472879,3488	1106999,1742
44	472873,8530	1107021,6380
45	472864,7508	1107019,4074
46	472870,2193	1106996,9588
47	472874,7704	1106992,3084
48	472876,0923	1106986,8554

	SO 101 - Souřadnice S-JTSK	
č.b.	Y	X
49	472864,9683	1106980,8794
50	472871,6289	1106953,4005
51	472842,5503	1106946,3496
52	472849,8921	1106916,0607
53	472873,9233	1106917,2700
54	472896,7359	1106927,4031
55	472870,8821	1106917,8506
56	472861,2471	1106915,5149
57	472867,5337	1106889,5820
58	472877,1643	1106891,9167
59	472879,7638	1106888,8468
60	472880,1878	1106887,0974
61	472871,2467	1106884,9302
62	472870,8227	1106886,6795
63	472867,9742	1106886,0714
64	472869,6813	1106879,0277
65	472870,1524	1106877,0840
66	472871,1362	1106873,0247
67	472844,6094	1106866,8099
68	472843,6958	1106870,6271
69	472835,5521	1106904,3470
70	472826,6844	1106902,1975
71	472823,9777	1106913,3589
72	472820,6520	1106929,6992
73	472827,6370	1106931,4651
74	472823,3570	1106948,9643
75	472780,2648	1106938,4802
76	472767,1628	1106937,0756
77	472777,0208	1106956,6494
78	472790,5782	1106959,9360
79	472787,3284	1106973,5536
80	472777,9986	1106971,2919
81	472775,6754	1106980,8760
82	472762,0682	1106977,5827
83	472765,4292	1106963,7174
84	472774,7591	1106965,9791
85	472764,6431	1106947,4526
86	472753,2927	1106994,1969
87	472734,3465	1106989,9523
88	472750,9304	1106997,3723
89	472751,9091	1106998,3170
90	472752,0573	1106999,6691
91	472750,9627	1107004,1846
92	472748,2505	1107007,8967
93	472743,7072	1107008,5996
94	472728,3475	1107004,8460
95	472740,7492	1107010,3473
96	472741,9146	1107011,1457

	SO 101 - Souřadnice S-JTSK	
č.b.	Y	X
97	472742,2617	1107012,5151
98	472751,1259	1107014,6815
99	472758,2614	1107016,5229
100	472761,8894	1107001,5565
101	472785,4374	1107001,7582
102	472790,2066	1106982,0532
103	472843,9075	1106995,1126
104	472839,1475	1107014,7575
105	472844,7303	1107021,8498
106	472847,2574	1107022,4614
107	472846,5668	1107025,6172
108	472848,3151	1107026,0454
109	472847,6007	1107028,9626
110	472845,8524	1107028,5345
111	472845,2939	1107030,4786
112	472842,7685	1107029,8602
113	472843,1710	1107027,8803
114	472841,4267	1107027,4563
115	472842,1362	1107024,5378
116	472843,8852	1107024,9629
117	472880,8922	1106984,6430
118	472877,6363	1106976,6398
119	472865,7159	1106978,1347
120	472885,3298	1106974,1633
121	472878,5842	1106975,0092
122	472877,0407	1106975,2028
123	472870,3433	1106959,0439
124	472871,2940	1106957,2446
125	472879,4168	1106942,5129
126	472890,2670	1106953,7486
127	472890,9646	1106950,8721
128	472880,7004	1106940,2433
129	472888,9784	1106925,6072
130	472887,4627	1106925,2401
131	472879,6136	1106939,1179
132	472867,3996	1106926,4700
133	472871,3879	1106921,3478
134	472869,7883	1106920,9606
135	472866,3472	1106925,3802
136	472859,7264	1106918,5242
137	472855,1903	1106917,4259
138	472864,7958	1106927,3726
139	472854,9488	1106940,0194
140	472846,3134	1106931,1644
141	472845,8972	1106932,8817
142	472854,0186	1106941,2141
143	472848,8881	1106947,8035
144	472850,4873	1106948,1911

	SO 101 - Souřadnice S-JTSK	
č.b.	Y	X
145	472855,0755	1106942,2984
146	472864,0150	1106951,4701
147	472866,7576	1106952,1348
148	472856,0057	1106941,1037
149	472865,8483	1106928,4625
150	472878,3300	1106941,3875
151	472871,7255	1106953,3417
152	472869,0431	1107003,8321
153	472874,3848	1107018,5036
154	472842,1600	1107001,1892
155	472788,8538	1106988,2673
156	472796,8449	1106983,9490
157	472792,1887	1107003,0958
158	472834,9068	1106993,3603
159	472830,4465	1107012,1893
160	472824,0164	1107010,7574
161	472818,9478	1106989,3070
162	472814,0718	1106988,1517
163	472800,0172	1107004,5791
164	472790,7642	1107008,9245
165	472788,9100	1107016,5779
166	472822,0579	1107016,5442
167	472820,2549	1107024,1510
168	472754,9333	1106984,7066
169	472741,2267	1107007,6687
170	472736,4449	1106991,3030
171	472728,0462	1106970,9777
172	472724,7055	1106971,1025
173	472827,9691	1107001,2249
174	472825,0535	1107000,5181
175	472803,7557	1106995,3580
176	472800,8402	1106994,6512
177	472870,6878	1106992,0077